



BLOM-SINGER® PROSTHESIS SIZER DILATOR

- ▶ The Blom-Singer® Prosthesis Sizer Dilator is used to keep the shunt open while changing the prosthesis
- ▶ Using the Dilator, the shunt channel can be dilated in one step during placement of a voice prosthesis and used to measure the size with the scale
- ▶ The dilator is available in two sizes: size 18 Fr. is suitable for all 16 Fr. voice prosthesis and size 22 Fr. is suitable for all 20 Fr. shunt valves



Single patient use



Consult instructions for use

Order information:

Blom-Singer® Prosthesis Sizer Dilator

18 Fr. (for 16 Fr. voice prosthesis)

BE2051

Blom-Singer® Prosthesis Sizer Dilator

22 Fr. (for 20 Fr. voice prosthesis)

BE2052